

PARTS LIST


ATV-110F - SINGLE A-ARM, SHAFT DRIVE

ASSY. NO. REF.NO DESCRIPTION

FIG. 1 - CYLINDER HEAD COVER

Price

Bitmap




110F-1-1	COVER, CYLINDER HEAD	8.32
110F-1-2	COVER, R. CYLINDER HEAD SIDE	10.56
110F-1-3	COVER, L. CYLINDER HEAD SIDE	10.40
110F-1-4	CAP, TAPPET ADJUSTING HOLE	2.88
110F-1-5	GASKET, CYLINDER HEAD COVER	5.00
110F-1-6	GASKET, R. CYLINDER HEAD COVER	5.00
110F-1-7	GASKET, L CYLINDER HEAD COVER	5.00
110F-1-8	NUT, CAP, 7MM	2.00
110F-1-9	WASHER, SEALING, 7MM	2.00
110F-1-10	WASHER A, SEALING, 7MM	2.00
110F-1-11	WASHER, SEALING, 6.5x12	2.00
110F-1-12	O-RING, 30.8x3	2.00
110F-1-13	BOLT, FLANGE, 6x110	2.40

110F-1-14	BOLT, FLANGE, 6×20	2.00
110F-1-15	PLUG, SPARK	7.00

FIG. 2 - CYLINDER HEAD


Bitmap



2-A	110F-2-1	HEAD COMP., CYLINDER	346.72
	110F-2-2	GUIDE, IN. VALVE	2.00
	110F-2-3	GUIDE, EX. VALVE	2.00
	110F-2-13	O-RING, 25×2.4	2.00
	110F-2-4	GASKET, ASSY., CYLINDER HEAD	9.92
	110F-2-5	GASKET, INSULATOR	2.00
	110F-2-6	COLLAR, 14.8MM	2.00
	110F-2-7	INSULTOR, CARBURETOR	2.00
	110F-2-8	PIPE, IN	16.96
	110F-2-10	BOLT, 6MM	2.00
	110F-2-11	COLLAR, 9.5MM	2.00
	110F-2-12	O-RING, 14.5MM	2.00
	110F-2-14	O-RING, 9×1.6	2.00
	110F-2-15	GASKET, RUBBER, 9MM	2.00

110F-2-16	BOLT, FLANGE, 6×25	2.00
110F-2-17	BOLT, FLANGE, 6×28	2.00
110F-2-18	CYLINDER	149.92
110F-2-19	GASKET, CYLINDER	6.00
110F-2-20	PACKING, RUBBER, 16MM	2.00
110F-2-21	PIN, DOWEL, 8×14	2.00

FIG. 3 - CRANKCASE
Bitmap




110F-3-1	CRANKCASE COMP., R.	113.92
110F-3-2	GASKET, CRANKCASE	8.32
110F-3-3	CRANKCASE COMP., L.	170.88
110F-3-4	TUBE, BREATHER, 5×320	4.64
110F-3-5	CLAMPER, OVER FLOW PIPE	3.20
110F-3-6	BOLT A, CYLINDER STUD, 6×198	2.88
110F-3-7	BOLT B, CYLINDER STUD, 6×205.5	2.88
110F-3-8	PACKING, DRAIN PLUG, 12.5×20	2.00
110F-3-9	PIN A, KNOCK, 10×14	2.00
110F-3-10	BOLT, DRAIN PLUG, 12MM	2.88
110F-3-11	CLIP, TUBE	2.00

110F-4-19 BOLT, FLANGE, 6x65

2.40

FIG. 5 - LEFT CRANKCASE COVER


Bitmap



110F-5-1	COVER, L. CRANKCASE	113.28
110F-5-2	EMBLEM, ENGINE LEFT COVER	10.56
110F-5-3	GASKET, L. CRANKCASE COVER	6.52
110F-5-4	CLAMPER	3.20
110F-5-5	SWITCH ASSY., CHANGE	10.56
110F-5-6	CAP, A.C. GENERATOR	2.40
110F-5-7	BOLT	2.00
110F-5-8	PIN, DOWEL,	2.00
110F-5-9	O-RING, 13.8x2.5	2.00
110F-5-10	BOLT, FLANGE, 6x50	2.40
110F-5-11	BOLT, FLANGE, 6x12	2.00
110F-5-12	BOLT, FLANGE, 6x16	2.00
110F-5-13	BOLT, FLANGE, 6x28	2.00
110F-5-14	BOLT, FLANGE, 6x32	2.00
110F-5-15	BOLT, FLANGE, 6x70	2.88

FIG. 6 - CRANKSHAFT PISTON

Bitmap



6-A	110F-6-1	CRANKSHAFT COMP.	373.60
	110F-6-2	RING SET, PISTON	59.52
	110F-6-3	PISTON	28.48
	110F-6-4	PIN, PISTON	3.52
	110F-6-5	CLIP, PISTON PIN, 13MM	2.00

FIG. 7 - ONE WAY CLUTCH

Bitmap




110F-7-A

ONE WAY CLUTCH COMPLETE

216.00

FIG. 8 - CLUTCH

Bitmap




110F-8-A

CLUTCH COMPLETE

220.00

FIG. 9 - CAMSHAFT / VALVE


Bitmap



	110F-9-1	SEAL, VALVE	12.00
	110F-9-2	CAMSHAFT COMP.	54.40
	110F-9-3	PLATE COMP., STOPPER	6.24
9-A	110F-9-4	ARM, VALVE ROCKER	12.96
	110F-9-13	SCREW, TAPPET ADJUSTING	4.00
	110F-9-14	NUT, TAPPET ADJUSTING	4.00
	110F-9-5	SHAFT, VALVE ROCKER ARM	4.00
9-B	110F-9-6	VALVE, IN	29.92
	110F-9-7	VALVE, EX	29.92
9-C	110F-9-8	SPRING, VALVE OUTER	4.32
	110F-9-9	SPRING, VALVE INNER	4.32
	110F-9-10	RETAINER, VALVE SPRING	2.00
	110F-9-11	SEAT, VALVE SPRING OUTER	2.00
	110F-9-12	COTTER, VALVE	2.00

FIG. 10 - CAM CHAIN / TENSIONER

Bitmap



10-A	110F-10-1	SPROCKET, CAM 928T	15.00
	110F-10-2	ARM COMP., CAM CHAIN TENSIONER	4.00
	110F-10-3	ROLLER, CAM CHAIN TENSIONER	4.00
	110F-10-4	PIVOT, CAM CHAIN TENSIONER	4.00
	110F-10-5	SPRING, CAM CHAIN TENSIONER	4.00
	110F-10-6	ROD COMP., CAM CHAIN TENSIONER PUSH	4.00
	110F-10-7	HEAD, CAM CHAIN TENSIONER PUSH ROD	4.00
	110F-10-8	ROLLER COMP., CAM CHAIN GUIDE	2.24
	110F-10-9	PIN, CAM CHAIN GUIDE ROLLER	4.00
	110F-10-10	SPROCKET, CAM CHAIN GUIDE	6.56
	110F-10-11	SPINDLE, CAM CHAIN GUIDE SPROCKET	7.20
	110F-10-12	CHAIN, CAM	30.24
	110F-10-13	BOLT, SEALING, 14MM	4.00
	110F-10-14	BOLT, KNOCK, 5MM	4.00
	110F-10-15	WASHER, SEALING 14MM	4.00
	110F-10-16	WASHER, 8MM	4.00


FIG. 11 - CARBURATOR

Bitmap



110F-11-1	CARBURETOR ASSY	234.08
110F-11-29	PIPE	2.88
110F-11-30	JOINT, AIR CLEANER	18.72
110F-11-31	CLAMP, HOSE	4.80


FIG. 12 - GENERATOR



12-A	110F-12-1	GENERATOR ASSY., FLYWHEEL TYPE A.C	210.00
	110F-12-2	FLYWHEEL COMP.	90.00
	110F-12-3	STATOR COMP.	120.00
	110F-12-7	BOLT, HEX., 5x10	2.00
	110F-12-9	BOLT, FLANGE, 6x22	2.00
	110F-12-4	CLAMPER, A.C. GENERATOR CORD	3.20
	110F-12-5	WASHER, 10MM	2.00
	110F-12-6	BOLT, HEX., 5x6	2.00
	110F-12-8	NUT, FLANGE, 10MM	2.00

FIG. 13 - STARTING CLUTCH


Bitmap



13-A	110F-13-1	PLATE, OIL SEPARATE	6.88
	110F-13-2	CHAIN, STARTING	14.08
	110F-13-3	GUIDE, STARTER CHAIN	2.00
	110F-13-4	PROTECTOR, STARTER CHAIN	2.00
	110F-13-5	SPROCKET COMP. STARTING	81.28
	110F-13-6	PLATE, STARTING SPROCKET SETTING	2.00
	110F-13-7	OUTER, STARTING CLUTCH	68.96
	110F-13-8	SPRING, STARTING CLUTCH ROLLER	2.00
	110F-13-9	CAP, STARTING CLUTCH ROLLER SPRING	2.00
	110F-13-10	PLATE, STARTING CLUTCH SIDE	2.00
	110F-13-13	ROLLER, 10x10	2.00
	110F-13-14	ROLLER, 5x11.8	2.00
	110F-13-14	SCREW, FLAT, 6x16	2.00
	110F-13-11	CIRCLIP, INTERNAL, 23MM	3.00
	110F-13-12	BEARING, NEEDLE, 19x23x13	12.00
	110F-13-15	OIL SEAL, 30x42x4.5	5.00
	110F-13-16	OIL SEAL, 18.9x28x5	5.00
	110F-13-17	O-RING, 107x2	12.00
	110F-13-18	O-RING, 6x1.7	4.00
	110F-13-20	BOLT, FLANGE, 6x10	2.00

FIG. 14 - STARTING MOTOR

Bitmap



110F-14-1

STARTER MOTOR ASSY

159.20


FIG. 15 - OIL PUMP

Bitmap

110F-15-1	PUMP ASSY., OIL	14.08
110F-15-2	GASKET, OIL PUMP BODY	6.00
110F-15-8	PIVOT, OIL FILTER	2.00
110F-15-9	SCREEN, OIL FILTER	2.00
110F-15-11	SCREW, PAN, 6×16	2.00
110F-15-12	SCREW, PAN, 6×22	2.00

FIG. 16 - GEARSHIFT DRUM

Bitmap




16-A	110F-16-1	FORK, GEARSHIFT	59.20
	110F-16-2	PIN, GEARSHIFT FORK GUIDE	
	110F-16-3	CLIP, GEARSHIFT FOTK GUIDE PIN	
	110F-16-4	DRUM, GEARSHIFT	
	110F-16-6	ROLLER, 4×10	
	110F-16-7	PLATE, GEARSHIFT DRUM STOPPER	
	110F-16-8	PIN, GEARSHIFT DRUM	
	110F-16-16	BOLT, KNOCK, 6MM	
	110F-16-19	ROLLER, 3×8.5	

	110F-16-5	PIECE, CHANGE SWITCH DRIVER	2.00
	110F-16-9	SPINDLE COMP., GEARSHIFT DRUM	2.24
	110F-16-10	SPRING, SHIFT DRUM STOPPER	2.00
16-B	110F-16-11	SPINDLE COMP., GEARSHIFT	82.72
	110F-16-12	ARM COMP., GEARSHIFT	32.00
	110F-16-13	SPRING, GEARSHIFT ARM	16.00
	110F-16-14	SPRING, GEARSHIFT RETURN	12.00
	110F-16-23	LEVER COMP., CLUTCH	14.00
	110F-16-15	PIN, SHIFT RETURN SPTRING	3.20
	110F-16-17	OIL SEAL, 11.6×24×10	4.16
	110F-16-18	BOLT, SOCKET, 6×16	2.00
16-C	110F-16-20	PEDAL, CHANGE	46.72
	110F-16-21	RUBBER, CHANGE PEDAL	2.00
	110F-16-22	BOLT, M6 X 20	2.00

FIG. 17 - TRANSMISSION

Bitmap




17-A	110F-17-1	MAINSHAFT, TRANSMISSION (12T)	148.32
	110F-17-5	GEAR, MAINSHAFT SECOND (17T)	
	110F-17-7	GEAR, MAINSHAFT THIRD (21T)	
	110F-17-8	GEAR, COUNTERSHAFT THIRD (26T)	

17-B	110F-17-9	GEAR, MAINSHAFT FOURTH (24T)	
	110F-17-18	WASHER, SPLINE, 17MM	
	110F-17-20	CIRCLIP, EXTERNAL, 17MM	
	110F-17-2	COUNTERSHAFT	226.24
	110F-17-3	GEAR, COUNTERSHAFT LOW (34T)	
	110F-17-4	BUSH, 209	
	110F-17-6	GEAR, COUNTERSHAFT THIRD (21T)	
	110F-17-10	GEAR, COUNTERSHAFT FOURTH (23T)	
	110F-17-13	COLLAR	
	110F-17-14	SPRING	
	110F-17-15	PLATE, GEARSHIFT DRUM LOCK	
	110F-17-16	WASHER, THRUST, 17MM	
	110F-17-17	WASHER, SPLINE	
	110F-17-19	WASHER, SPLINE, 20MM	
	110F-17-21	CIRCLIP, 20MM	
	110F-17-11	BEARING, RADIAL BALL, 6203	15.04
	110F-17-12	BEARING, RADIAL BALL, 6202	14.40
	110F-17-22	OIL SEAL, 17295	3.68
	110F-17-23	BEARING, RADIAL BALL, 6001	15.04

FIG. 18 - REAR CRANKCASE COVER


Bitmap



18-A	110F-18-A	REAR CRANKCASE - COMPLETE	252.16
	110F-18-20	OUTER COVER, RR. CRANKCASE	31.20

FIG. 19 - FRAME


Bitmap



110F-19-1	FRAME COMPLETE	561.92
110F-19-2	BOLT, FLANGE	3.20
110F-19-3	BOLT, FLANGE	3.20
110F-19-4	NUT, SELF-LOCKING	2.00
110F-19-5	BUSH, SOLID	6.24
110F-19-6	NIPPLE, GREASE	2.00
110F-19-7	BUSH, 1	6.24
110F-19-8	PIPE	3.20
110F-19-9	TOOL KIT	31.20

FIG. 20 - FRONT FENDER


Bitmap



110F-20-1	FRONT FENDER COMP., BLUE	312.16
110F-20-1	FRONT FENDER COMP., RED	312.16
110F-20-2	ELEMENT, AIR CLEANER	24.96
110F-20-3	PLATE	3.20
110F-20-4	PLATE, ELEMENT	9.28
110F-20-5	GUIDE	6.24
110F-20-6	SCREW, TAPPING	2.00
110F-20-7	WASHER	2.00
110F-20-8	HOOK	2.00
110F-20-9	HOOK	3.20
110F-20-10	CAP, CLEANER CASE 1	62.40
110F-20-11	SEAL	3.20
110F-20-12	BOLT	2.00
110F-20-13	BOLT, WITH WASHER	2.00
110F-20-14	NUT, SPRING	2.00
110F-20-15	FENDER, FRONT 2, BLUE	62.40
110F-20-15	FENDER, FRONT 2, RED	62.40
110F-20-16	BOLT, HEXAGON SOCKET HEAD	2.00
110F-20-17	COVER, TOP, BLUE	31.20
110F-20-17	COVER, TOP, RED	31.20
110F-20-18	RIVET	2.00
110F-20-19	STAY, FENDER 1	62.40
110F-20-20	BOLT, FLANGE	2.00
110F-20-21	SCREW, BINDING	2.00
110F-20-22	NUT, SELF-LOCKING	2.00
110F-20-23	DUCT	3.20

FIG. 21 - REAR FENDER

Bitmap



110F-21-2	REAR FENDER COMP. RED	312.16
110F-21-2	REAR FENDER COMF. BLUE	312.16
110F-21-3	STAY, FENDER 1	18.72
110F-21-4	STAY, FENDER 2	18.72
110F-21-5	GROMMET	2.00
110F-21-6	BOLT, FLANGE	2.00
110F-21-7	BOLT, WITH WASHER	2.00


FIG. 22 - DRIVE SHAFT

Bitmap

110F-22-1	REAR ARM COMP.	224.80
110F-22-2	AXLE.,WHEEL	9.28
110F-22-3	WASHER, PLATE	2.00
110F-22-4	BOOT, RUBBER	16.32
110F-22-5	CLAMP, HOSE	2.00
110F-22-6	NUT, SELF-LOCKING	2.00
110F-22-7	COVER	24.96
110F-22-8	BOLT, FLANGE	2.00

FIG. 23 - DRIVE SHAFT

Bitmap




110F-23-1	HOUSING, DRIVE SHAFT	618.08
110F-23-2	BREATHER	6.24
110F-23-3	HOSE (L1200)	3.20
110F-23-4	COUPLING, GEAR	15.68
110F-23-5	PLUG, STRAIGHT SCREW	2.40
110F-23-6	GASKET	2.00
110F-23-7	PLUG, OIL LEVEL	3.20
110F-23-8	O-RING	2.00
110F-23-9	DRIVE PINION COMP.	109.28
110F-23-10	SPACER	9.28

110F-23-11	O-RING	2.00
110F-23-12	OIL SEAL	3.20
110F-23-13	BEARING (B6303)	24.96
110F-23-14	NUT	2.00
110F-23-15	REAR AXLE	355.04
110F-23-16	BEARING	24.96
110F-23-17	OIL SEAL	3.20
110F-23-18	O-RING	2.00
110F-23-19	BOLT, FLANGE	2.00
110F-23-20	SHAFT, DRIVE	21.92
110F-23-21	CROSS JOINT COMP.	93.76
110F-23-22	BOLT	2.00
110F-23-23	WASHER, SPRING	2.00
110F-23-24	RING, GEAR	120.16

FIG. 24 - REAR SUSPENSION

Bitmap




110F-24-1	SHOCK ABSORBER ASSY, REAR	287.20
110F-24-2	.BUSH, REAR SHOCK ABSORBER	N/A
110F-24-3	BOLT, FLANGE	2.00
110F-24-4	NUT, SELF-LOCKING	2.00

FIG. 25 - STEERING

Bitmap


Bitmap



110F-25-1	COLUMN, STEERING 2	240.32
110F-25-2	PLUG, TAPER	3.20
110F-25-3	HOLDER, HANDLE UNDER	12.48
110F-25-4	HOLDER, HANDLE	6.24
110F-25-5	BOLT, FLANGE	2.00
110F-25-6	PLANE BEARING, STEERING	9.28
110F-25-7	OIL SEAL	2.00
110F-25-8	SPACKET, STEERING LOWER	4.64
110F-25-9	BOLT	2.00
110F-25-10	WASHER, LOCK 1	2.00
110F-25-11	COLLAR	2.00
110F-25-12	WASHER, PLATE	2.00
110F-25-13	NUT, SELF-LOCKING	2.00
110F-25-14	PIN, COTTER	2.00
110F-25-15	TIE ROD ASSY.	418.24

FIG. 26 - FRONT SUSPENSION


Bitmap



110F-26-1	SWING ARM RIGHT	124.80
110F-26-2	SWING ARM LEFT	124.80
110F-26-3	SHOCK ABSORBER ASSY	75.84
110F-26-4	BOLT	3.20
110F-26-5	BOLT	3.20
110F-26-6	BOLT	3.20
110F-26-7	NUT, SELF-LOCKING	2.00
110F-26-11	STEERING KNUCKLE ASSY (RIGHT)	184.16
110F-26-12	STEERING KNUCKLE ASSY (LEFT)	184.16
110F-26-13	BOLT	3.20
110F-26-14	NUT, CASTLE	2.00
110F-26-15	PIN, COTTER	2.00

FIG. 27 - FUEL TANK

Bitmap



110F-27-1	FUEL TANK COMP.	213.12
110F-27-2	CAP ASSY	17.12
110F-27-3	HOSE (L340)	2.00
110F-27-4	GROMMET	3.20
110F-27-5	COLLAR	3.20
110F-27-6	COLLAR	2.00
110F-27-7	BOLT	2.00
110F-27-8	GROMMET	3.20
110F-27-9	WASHER, PLATE	2.00
110F-27-10	FUEL COCK ASSY 1	28.00
110F-27-11	SCREW	2.00
110F-27-12	HOSE (L145)	3.20
110F-27-13	CLIP	2.00
110F-27-14	DAMPER, LOCATING 1	3.20
110F-27-15	DAMPER	3.20

FIG. 28 - SEAT

Bitmap




110F-28-1

SINGLE SEAT ASSY

131.20

FIG. 29 - FRONT WHEEL

Bitmap



110F-29-1

HUB, FRONT

105.12

110F-29-2

BOLT

2.00

110F-29-3

SPACER, BEARING

N/A

110F-29-4

BEARING (B6003)

32.00

110F-29-5

OIL SEAL

8.00

110F-29-8

RING 1

12.00

110F-29-6

WHEEL COMP., FRONT

96.00

110F-29-7

NUT, FLANGE

2.00

110F-29-9

TIRE, FRONT (19×7-8)

98.00

110F-29-10

VALVE, RIM

3.20

110F-29-11

COLLAR

2.00

110F-29-12

NUT, CASTLE

2.00

110F-29-13

PIN, COTTER

2.00

110F-29-14

PLATE, BRAKE SHOE

99.04

110F-29-15


BRAKE SHOE SET

24.00

110F-29-16	SPRING, TENSION	4.00
110F-29-17	CAMSHAFT	5.00
110F-29-18	LEVER, CAMSHAFT 1	6.00
110F-29-19	BOLT	2.00
110F-29-20	NUT	2.00
110F-29-21	PLATE, INDICATOR	2.00
110F-29-22	OIL SEAL	5.00

FIG. 30 - REAR WHEEL

Bitmap




	110F-30-1	COLLAR, WHEEL	37.44
	110F-30-2	.BOLT	2.00
	110F-30-3	REAR WHEEL COMP.	95.00
	110F-30-4	NUT, FLANGE	2.00
	110F-30-5	TIRE, REAR (18×9.50-8)	98.00
	110F-30-6	VALVE, RIM	3.20
30-A	110F-30-7	HUB, REAR	78.24
	110F-30-8	SPACER, BEARING	18.00

	110F-30-9	BEARING	18.00
	110F-30-10	OIL SEAL	5.00
	110F-30-11	OIL SEAL	5.00
	110F-30-12	NUT, AXLE	3.00
	110F-30-13	CAMSHAFT	2.00
	110F-30-14	LEVER, CAMSHAFT	2.00
	110F-30-15	HOOK, SPRING	2.00
	110F-30-16	BOLT	2.00
	110F-30-17	NUT	2.00
	110F-30-18	PLATE, INDICATOR	2.00
	110F-30-21	PIN, PIVOT	2.00
	110F-30-22	BOLT, SERRATION	2.00
	110F-30-32	SPRING, TENSION	2.00
30-B	110F-30-19	BRAKE SHOE SET	31.84
	110F-30-20	SPRING, TENSION	2.00
	110F-30-23	DRUM, BRAKE	87.36
30-C	110F-30-24	BOSS	25.60
	110F-30-27	O-RING	2.00
	110F-30-25	WASHER	2.00
	110F-30-26	NUT	2.00
	110F-30-28	NUT	2.00
	110F-30-29	NUT	2.00
	110F-30-30	COVER1	93.76
	110F-30-31	SCREW, PAN HEAD	2.00
	110F-30-33	NUT, CASTLE	3.20
	110F-30-34	PIN, COTTER	2.00

FIG. 31 - STEERING HANDLE, CABLE


Bitmap



	110F-31-1	HANDLEBAR	40.64
	110F-31-2	GRIP	10.88
	110F-31-3	PROTECTOR, HANDLEBAR, BLUE	31.20
	110F-31-3	PROTECTOR, HANDLEBAR, RED	31.20
	110F-31-4	CABLE, THROTTLE 1	22.00
31-A	110F-31-5	CABLE, BRAKE	26.00
31-9	110F-31-9	THROTTLE LEVER ASSY	62.40
31-B	110F-31-27	CABLE, BRAKE	26.00

FIG. 32 - STAND , FOOTREST

Bitmap




110F-32-1	COVER, FOOTREST	12.48
110F-32-2	FOOTREST 1	37.44
110F-32-3	FOOTREST 2	37.44
110F-32-4	BOLT, FLANGE	2.00
110F-32-5	PEDAL, BRAKE	37.44

110F-32-6	SPRING, TENSION	2.00
110F-32-7	ROD, BRAKE	23.36
110F-32-11	NUT, ADJUSTING	2.00
110F-32-12	SPRING, COMPRESSION	2.00
110F-32-13	PIN	2.00
110F-32-8	PIN, CLEVIS	2.00
110F-32-9	WASHER	2.00
110F-32-10	PIN, COTTER	2.00
110F-32-14	NERF BAR RIGHT	56.00
110F-32-15	NERF BAR LEFT	56.00
110F-32-16	BOLT, FLANGE	2.00

FIG. 33 - FRONT BUMPER


Bitmap



110F-33-1	BOLT, FLANGE	2.00
110F-33-2	BAR, CARRY FRONT	118.72

FIG. 34 - HEADLIGHT


Bitmap



110F-34	HEADLIGHT - COMPLETE	38.00
110F-34-5	HEADLIGHT BULB	7.00

FIG. 35 - HANDLE SWITCH LEVER


Bitmap



110F-35-1	LEVER HOLDER ASSY (LEFT)	31.20
110F-35-14	SWITCH, HANDLE 2	46.72

FIG. 36 - ELECTRICAL

Bitmap



110F-36-1	C.D.I. UNIT ASSY	65.00
110F-36-2	IGNITION COIL ASSY	24.00
110F-36-3	SCREW, HEXAGON	2.00
110F-36-4	PLUG CAP ASSY	6.24
110F-36-5	STOP SWITCH	6.24
110F-36-6	SPRING, STOP SWITCH	2.00
110F-36-7	RECTIFIER®ULATOR ASSY	37.44
110F-36-8	SCREW, PAN HEAD	2.00
110F-36-9	STARTER RELAY ASSY	22.00
110F-36-10	NUT	2.00
110F-36-11	WASHER SPRING	2.00
110F-36-12	RELAY ASSY	21.12
110F-36-13	BATTERY ASSY	66.00
110F-36-14	HOSE (L450)	2.00
110F-36-15	WIRE, PLUS LEAD	2.00
110F-36-16	BAND, BATTERY	3.20
110F-36-17	SEAT, BATTERY	2.00
110F-36-18	FUSE HOLDER ASSY	2.00
110F-36-19	.FUSE (5A)	2.00
110F-36-20	PILOT LIGHT ASSY	6.24
110F-36-21	.BULB (14V-1.7W)	2.00
110F-36-22	CLAMP, HOSE	2.00
110F-36-23	CLAMP	2.00
110F-36-24	BAND, SWITCH CORD	2.00
110F-36-25	MAIN SWITCH ASSY	34.00


FIG. 37 - REAR REFLECTOR

Bitmap

110F-37-1	REAR REFLECTOR ASSY	6.00
110F-37-2	NUT	2.00
110F-37-3	REFLECTOR, FRONT 1	15.68
110F-37-4	REFLECTOR, REAR	15.68

FIG. 38 - MUFFLER


Bitmap



110F-38-1	MUFFLER - COMPLETE	301.44
110F-38-7	GASKET, EXHUST PIPE	6.00

FIG. 39 - REAR LAMP

Bitmap



110F-39-1	REAR LAMP ASSY. - COMPLETE	40.64
110F-39-3	BULB	7.00

FIG. 40 - WIRE HARNESS

Bitmap

110F-40-1	WIRE, HARNESS	34.24
110F-SM1	SERVICE MANUAL	12.80
110F-OM1	OWNER'S MANUAL	9.60