

PARTS LIST


ATV250 - SHAFT DRIVE

REF. NO

DESCRIPTION

PRICE


FIG. 1 PNEUMATIC MECHANISM



ATV250- 1-1	PNEUMATIC CAM SHAFT ASSY	133.28
ATV250- 1-2	column pin	2.40
ATV250- 1-3	Roll bearing	19.36
ATV250- 1-4	Roll bearing	6.56
ATV250- 1-5	TIMING SPROCKET	40.32
ATV250- 1-6	BOLT M10×1.25×25	2.00
ATV250- 1-7	WASHER	2.00
ATV250- 1-8	TIMING CHAIN	92.80
ATV250- 1-9	LOWER GUIDE PLATE	47.04
ATV250- 1-10	UPPER GUIDE PLATE ASSY	68.80
ATV250- 1-11	CHAIN TENSIONER	85.60
ATV250- 1-12	SHIM OF TENSIONER	2.00
ATV250- 1-13	BOLT 95026-06025	2.00
ATV250- 1-14	BOLT 95026-06014	2.00
ATV250- 1-15	AIR VALVE	104.80
ATV250- 1-16	VALVE SPRING SEAT	12.48
ATV250- 1-17	VALVE SPRING	14.72
ATV250- 1-18	VALVE STEM OIL SEAL	20.32
ATV250- 1-19	VALVE SPRING COVER	45.28
ATV250- 1-20	VALVE LOCK CLIP	2.00
ATV250- 1-21	O-RING	9.92

ATV250- 1-22	ROCKER ARM SHAFT 2	17.12
ATV250- 1-23	ROCKER ARM SHAFT 1	17.12
ATV250- 1-24	VALVE ROCKER ARM ASSY	64.32


FIG. 2 cylinder cap



ATV250- 2-1	CYLINDER CAP UNIT	663.80
ATV250- 2-2	BOLT 95026-06010	2.00
ATV250- 2-3	WASHER	2.00
ATV250- 2-4	DAMPER	2.00
ATV250- 2-5	CYLINDER CAP SHIM UNIT	45.28
ATV250- 2-6	ALIGNMENT PIN 99510-14016	2.00
ATV250- 2-7	ALIGNMENT PIN	2.00
ATV250- 2-8	OIL SEAL	4.00
ATV250- 2-9	CAP NUT	5.28
ATV250- 2-10	WASHER	2.00
ATV250- 2-11	SCREW M8×45-10.9	2.00
ATV250- 2-12	WASHER 8	2.00
ATV250- 2-13	SPROCKET CHAMBER COVER UNIT	40.48
ATV250- 2-14	OIL BAFLE UNIT	10.24
ATV250- 2-15	AIR DRAIN	4.64
ATV250- 2-16	HOOF	2.00
ATV250- 2-17	O-RING	9.92
ATV250- 2-18	SCREW 98512-06012	2.00
ATV250- 2-19	O-RING	9.92
ATV250- 2-20	SCREW 98512-06020	2.00
ATV250- 2-21	UPPER VALVE COVER	11.84
ATV250- 2-22	LOWER VALVE COVER	12.32
ATV250- 2-23	O-RING	3.36
ATV250- 2-24	SCREW M6×18-10.9	2.00
ATV250- 2-25	PRESSURE PLATE	2.00
ATV250- 2-26	BOLT M6×12	2.00


ATV250- 2-27	STOP PLATE	2.00
ATV250- 2-28	SPARK PLUG	7.00

FIG. 3 CRANK CONNECTING ROD MECHANISM




ATV250- 3-1	CRANK CONNECTING ROD ASSY	652.20
ATV250- 3-2	WOODRUFF KEY 3×5×13	2.00
ATV250- 3-3	PISTON	59.04
ATV250- 3-4	PISTON RING ASSY	130.24
ATV250- 3-5	PISTON PIN	14.24
ATV250- 3-6	CIRCLIP	2.00
ATV250- 3-7	BLANCE SHAFT DRIVING GEAR	40.96
ATV250- 3-8	BLANCE SHAFT ASSY	114.40
ATV250- 3-9	Balance shaft driven gear	31.36
ATV250- 3-10	Roll bearing	12.32
ATV250- 3-11	Balance key	2.00
ATV250- 3-12	Balance shaft lock gasket	4.00
ATV250- 3-13	Balance shaft locknut	3.20
ATV250- 3-14	WOODRUFF KEY	2.00
ATV250- 3-15	BEARING 6306/c4	34.40
ATV250- 3-16	CIRCLIP 26	2.00
ATV250- 3-17	SCREW M6×18	2.00
ATV250- 3-18	PRESSURE PLATE	4.64
ATV250- 3-19	BEARING 6203	6.40
ATV250- 3-20	OIL SEAR	8.32
ATV250- 3-21	CYLINDER UNIT	328.00
ATV250- 3-22	CYLINDER SHIM	12.20
ATV250- 3-23	O-RING	2.00
ATV250- 3-24	ALIGNMENT PIN 99530-14016	2.00
ATV250- 3-25	SCREW M6×25-10.9	2.00

FIG. 4 CRANKCASE BODY PART




ATV250- 4-1	LEFT CRANKCASE COVER GASKET	8.40
ATV250- 4-2	PIN 99530-12016	4.48
ATV250- 4-3	LEFT CRANKCASE COVER	142.08
ATV250- 4-4	SCREW 98512-06080	2.00
ATV250- 4-5	SCREW 98512-06030	2.00
ATV250- 4-6	SCREW 98512-06025	2.00
ATV250- 4-7	SCREW 98512-06050	2.00
ATV250- 4-8	SCREW 98512-06060	2.00
ATV250- 4-9	RIGHT CONNECTING CASE GASKET	13.92
ATV250- 4-10	SCREW 98512-06040	2.00
ATV250- 4-11	RIGHT CRANKCASE COVER	227.60
ATV250- 4-12	RIGHT CONNECTING CASE	187.84
ATV250- 4-13	RIGHT CRANKCASE COVE GASKET	11.20
ATV250- 4-14	SCREW 98512-06070	2.00
ATV250- 4-15	OIL DIPSTICK	11.04
ATV250- 4-16	O-RING	3.04
ATV250- 4-17	RIGHT CRANKCASE ASSY	350.90
ATV250- 4-18	LEFT CRANKCASE ASSY	498.80
ATV250- 4-19	RIGHT DRIVING COVER	112.80
ATV250- 4-20	SCREW 98512-06030	2.00
ATV250- 4-21	ALIGNMENT PIN O10×14	2.00
ATV250- 4-22	SCREW 98512-06030	2.00
ATV250- 4-23	ALIGNMENT PIN O10×14	2.00
ATV250- 4-24	SCREW 98512-06060	2.00
ATV250- 4-25	SCREW 98512-06085	2.00
ATV250- 4-26	SCREW M6×160-10.9	3.36
ATV250- 4-27	SCREW 98512-06075	2.00
ATV250- 4-28	SPRUE	4.80
ATV250- 4-29	CIRCLIP 28	11.84
ATV250- 4-30	DOUBLE-HEAD SCREW	23.52

FIG. 5 CLUTCH




ATV250- 5-1	MAIN CLUTCH ASSY	474.20
ATV250- 5-2	WASHER	2.00
ATV250- 5-3	LOCKING WASHER	2.00
ATV250- 5-4	NUT	2.00
ATV250- 5-5	CLUTCH ASSY	345.00
ATV250- 5-5-1	Clutch driving friction tray	14.72
ATV250- 5-5-2	Clutch driven friction tray	14.72
ATV250- 5-6	BEARING 6000	76.80
ATV250- 5-7	CLUTCH POST ROD	5.44
ATV250- 5-8	LOCKING WASHER	2.00
ATV250- 5-9	NUT	2.00
ATV250- 5-10	GUIDE ROD	2.00
ATV250- 5-11	LOWER CAM PLATE	33.44
ATV250- 5-12	STEEL BALL BRACKET UNIT	5.60
ATV250- 5-13	UPPER CAM PLATE UNIT	44.64
ATV250- 5-14	PERATION ROCKER ARM UNIT	59.20
ATV250- 5-15	COMPRESSION SPRING	2.00
ATV250- 5-16	CONNECTING PIN 1.2×14	3.52
ATV250- 5-17	SUPPORT SEAT	9.92
ATV250- 5-18	WASHER 8	2.00
ATV250- 5-19	COTTER PIN	2.00
ATV250- 5-20	ADJUSTING SCRWE	2.00
ATV250- 5-21	O-RING	2.00
ATV250- 5-22	WASHER 8	2.00
ATV250- 5-23	LOCKING NUT	2.00

FIG. 6 gear shift OPERATION device



ATV250- 6-1	OIL SEAL	7.36
ATV250- 6-2	SHIFT ASSY	69.60
ATV250- 6-2-1	Shift lever	25.28
ATV250- 6-2-2	Shift axletree	41.92
ATV250- 6-2-3	shift limit pin 2	2.08
ATV250- 6-2-4	shift sprin	4.16
ATV250- 6-3	WASHER	2.00
ATV250- 6-4	LIMIT LEVER ASSY	14.08
ATV250- 6-5	LIMIT LEVER SPRING	2.20
ATV250- 6-6	SHIFT PEDAL ASSY	42.08

FIG. 7 reverse lever device




ATV250- 7-1	LEVER ASSY	154.70
ATV250- 7-2	WASHER	2.00
ATV250- 7-3	WASHER	2.00
ATV250- 7-4	SCREW	19.04

ATV250- 7-5

SCREW M6×20-10.9


2.00

FIG. 8 OUTPUT DEVICE

ATV250- 8-1	SCREW M8×25	2.00
ATV250- 8-2	PRESSURE PLATE	6.72
ATV250- 8-3	BEARING 6304	11.36
ATV250- 8-4	WASHER	2.00
ATV250- 8-5	FINN GEAR	347.90
ATV250- 8-6	FORWARD GEAR UNIT	491.80
ATV250- 8-7	REVERSE GEAR	430.40
ATV250- 8-8	NUT	15.84
ATV250- 8-9	BEARING 6006	14.24
ATV250- 8-10	WASHER	2.00
ATV250- 8-11	CONNECTING PAW	59.52
ATV250- 8-12	WASHER	2.00
ATV250- 8-13	BEARING	53.44
ATV250- 8-14	NUT SLEEVE	8.32
ATV250- 8-15	SHAPED LEFT HARDED	6.72
ATV250- 8-16	OUTPUT SHAFT	136.64
ATV250- 8-17	WASHER	2.00
ATV250- 8-18	BEARING	69.92
ATV250- 8-19	INTERNAL HEXAGONAL NUT	7.20
ATV250- 8-20	CROSS JOINT ASSY.	189.20
ATV250- 8-20-1	U shelf 2	44.00
ATV250- 8-20-2	U shelf 1	44.00
ATV250- 8-20-3	Cross	30.08
ATV250- 8-20-4	Cross bearing	44.48
ATV250- 8-20-5	Spring block ring for bearing-A	2.00
ATV250- 8-21	REAR COVER	40.32
ATV250- 8-22	O-RING	2.24
ATV250- 8-23	BOLT M8×25	2.00
ATV250- 8-24	REVERSE SHIFT FORK	49.12


ATV250- 8-25	COMPRESSION SPRING	2.00
ATV250- 8-26	STEEL BALL 6.35G100b	2.00
ATV250- 8-27	REVERSE SHIFT FORK SHAFT	10.72
ATV250- 8-28	REVERSE CONTROL LEVER UNIT	33.28
ATV250- 8-29	REVERS CONTROL SHAFT	44.32
ATV250- 8-30	CIRCLIP 14	2.00
ATV250- 8-31	OPERATION PLATE	7.04
ATV250- 8-32	LEVER PLATE	4.80
ATV250- 8-33	BOLT M6×16	2.00
ATV250- 8-34	OIL SEAL	8.64
ATV250- 8-35	O-RING	2.00
ATV250- 8-36		2.00
ATV250- 8-37		4.64

FIG. 9 change speed gear device




ATV250- 9-1	SPINDLE ASSY	389.76
ATV250- 9-2	BEARING 6204	9.12
ATV250- 9-3	OIL SEAL	8.16
ATV250- 9-4	BEARING 6202	9.12
ATV250- 9-5	DRIVE AXLE ASSY	374.08

FIG. 10 shift cam, shift fork device



ATV250-	10-1	SHIFT CAM AXLE ASSY	215.20
ATV250-	10-1-1	SHIFT CAM AXLE	110.72
ATV250-	10-1-2	Roller bearing	34.56
ATV250-	10-1-3	Start wheel	69.44
ATV250-	10-1-4	bolt	2.00
ATV250-	10-2	SHIFT FORK 2	39.36
ATV250-	10-3	SHIFT FORK 3	39.36
ATV250-	10-4	SHIFT FORK 1	39.36
ATV250-	10-5	LONG SHIFT FORK AXLE	4.96
ATV250-	10-6	SHORT SHIFT FORK AXLE	4.96


FIG. 11 HAND STARTING



ATV250-	11-1	HAND STARTING ASSY	176.40
ATV250-	11-2	SCREW 98512-06020	1.00
ATV250-	11-3	BOSS ONE-WAY UNIT	77.92


ATV250- 11-4	O-RING	1.00
ATV250- 11-5	WASHER	1.60
ATV250- 11-6	WASHER	1.00
ATV250- 11-7	BOLT M10×125×40	1.60
ATV250- 11-8	OIL SEAL	8.96
ATV250- 11-9	BEARING	50.24
ATV250- 11-10	PRESSING PLATE	3.04
ATV250- 11-11	SCREW M5×16	1.00

FIG. 12 LUBRICATION SYSTEM




ATV250- 12-1	ENGINE OIL PUMP	159.04
ATV250- 12-2	SCREW M5×16	2.00
ATV250- 12-3	OIL PUMP PAD	3.65
ATV250- 12-4	ENGINE OIL COARSE STRAINER	6.88
ATV250- 12-5	COMPRESSING SPRING	2.00
ATV250- 12-6	OIL DRAIN PLUG SCREW	13.12
ATV250- 12-7	O-RING	2.56
ATV250- 12-8	ENGINE OIL FINE STRAINER	22.40
ATV250- 12-9	ENGINE OIL FINE STRAINER COVER	33.28
ATV250- 12-10	O-RING	5.12
ATV250- 12-11	SCREW M6×20-10.9	2.00
ATV250- 12-12	SCREW M6×115-10.9	2.24

FIG. 13 Electric starter




ATV250- 13-1	DUPLUX GO GEAR	45.12
ATV250- 13-2	GO GEAR AXLE	4.80
ATV250- 13-3	WASHER	2.00
ATV250- 13-4	CIRCLIP 12	2.00
ATV250- 13-5	GEAR ASSY OF ELECTRIC STARTER	65.76
ATV250- 13-6	WASHER	2.00
ATV250- 13-7	CLUTCH OF ELECTRIC STARTER ASSY	97.30
ATV250- 13-8	STARTING MOTOR	346.60
ATV250- 13-9	CONNECTING BOARD OF STARTING MOTOR	22.88
ATV250- 13-10	SCREW 97602-06115	2.00
ATV250- 13-11	MAGNETO	457.30
ATV250- 13-11-1	STATOR COMP	208.20
ATV250- 13-11-2	ROTOR ASSY	208.20
ATV250- 13-12	SCREW 97602-06215	2.00
ATV250- 13-13	SCREW 8*16	2.00

FIG. 14 INTAKE SYSTEM



ATV250-	14-1	CARBURETOR SEAT	28.00
ATV250-	14-2	SCREW M6×16	2.00
ATV250-	14-3	SCREW M6×16-10.9	2.00
ATV250-	14-4	AIR FILTER ASSY	98.10
ATV250-	14-4-1	FILTER CORE UNIT	64.16
ATV250-	14-5	CARBURETOR	282.40


FIG. 15 EXHAUST system



ATV250-	15-1	MUFFLER	364.32
ATV250-	15-1-1	EXHAUST PIPE UNIT 1	47.52
ATV250-	15-1-2	THERMAL PLATE UNIT OF EXHAUST PIPE	30.88
ATV250-	15-1-3	BOLT M6×10	2.00

ATV250-	15-1-4	SILENCER ASSY	273.44
ATV250-	15-1-5	EXHAUST PIPE WASHER	6.00
ATV250-	15-1-6	SCREW M6×20-10.9	7.84
ATV250-	15-1-7	SEAL RING OF EXHAUST PIPE	3.84
ATV250-	15-2	BOT M8×20	2.00
ATV250-	15-3	WASHER 8	2.00
ATV250-	15-4	WASHER 8	2.00


FIG. 16 FRAME, REAR SHOCK ABSORBER



ATV250-	16-1	FRAME	784.64
ATV250-	16-2	CONNECTIO PLATE COMBINATION ON ENGINE	59.36
ATV250-	16-3	BOLT M8×16	2.00
ATV250-	16-4	BOLT M8×55	2.00
ATV250-	16-5	BOLT M8×65	2.00
ATV250-	16-6	BOLT M8×105	2.08
ATV250-	16-7	NUT M8	2.00
ATV250-	16-8	BUSH, SOLID	2.00
ATV250-	16-9	NIPPLE, GREASE	2.88
ATV250-	16-10	REAR SHOCK ABSORBER	126.08
ATV250-	16-11	BOLT M12×75	2.24
ATV250-	16-12	NUT M12	2.00
ATV250-	16-13	REAR SHOCK ABSORBER PIN	4.32
ATV250-	16-14	WASHER 12	2.00
ATV250-	16-15	SPLIT PIN 3.2×24	2.00
ATV250-	16-16	REAR SHOCK ABSORING RUBBER PAD UNIT	2.00
ATV250-	16-17	CABLE CLIP 3	2.88


ATV250- 16-18	CABLE CLIP 2	2.88
ATV250- 16-19	Fan bracket	33.44
ATV250- 16-20	Fan	204.00

FIG. 17 FRONT SUSPENSION SYSTEM




ATV250- 17-1	FRONT LEFT WHEEL FORK WELD	166.40
ATV250- 17-1-1	RUBBER BUSHING	15.84
ATV250- 17-2	FRONT RIGHT WHEEL FORK WELD	166.40
ATV250- 17-3	BOLT M10×70	2.24
ATV250- 17-4	NUT M10	2.00
ATV250- 17-5	FRONT SHOCK ABSORBER	188.96
ATV250- 17-6	FRONT SHOCK ABSORBER NUT	5.92
ATV250- 17-7	CIRCLIP 32	2.00
ATV250- 17-8	FRONT RIGHT SEAT UNIT	95.04
ATV250- 17-9	FRONT LEFT SEAT UNIT	95.04
ATV250- 17-10	NUT M12×1.25	2.00
ATV250- 17-11	COTTER PIN 3.2×30	2.00
ATV250- 17-12	BOLT M12×50	2.00
ATV250- 17-13	NUT M12	2.00
ATV250- 17-14	DUST-PROOF COVER OF FRONT BALL JOINT	3.20

FIG. 18 FRONT WHEEL SYSTEM




ATV250-	18-1	FRONT RIM	128.00
ATV250-	18-2	FRONT TIRE	120.00
ATV250-	18-3	AIR CHAIN MOUTH WITHOUT TUBE	4.32
ATV250-	18-4	FRONT BRAKE ASSY	416.20
ATV250-	18-4-1	FRONT BRAKE SHOE	32.00
ATV250-	18-4-2	SPRING	3.60
ATV250-	18-4-3	FRONT BRAKE OIL SEAL	51.68
ATV250-	18-5	WHEEL NUT OF FRONT AND REAR WHEELS	2.88
ATV250-	18-6	WASHER 14-140HV	2.00
ATV250-	18-7	NUT M14	2.00
ATV250-	18-8	COTTER PIN 3.2×26	2.00
ATV250-	18-9	AIRFLOW PIPE OF FRONT BRAKE	6.24
ATV250-	18-10	CLAMP	2.88
ATV250-	18-11	CLAMP	2.88
ATV250-	18-12	DUST-PROOF COVER OF FRONT AND REAR WHEELS	4.00

FIG. 19 STEERING VERTICAL POLE




ATV250- 19-1	STEERING UPRIGHT COLUMN WELD	114.24
ATV250- 19-2	UPPER GRIPPER BLOCK OF STEERING BAR	8.16
ATV250- 19-3	LOWE GRIP SLIPER OF STEERING BAR	4.16
ATV250- 19-4	BOLT	2.00
ATV250- 19-5	BOLT	2.00
ATV250- 19-6	GRIP SLIPPER OF STEERING UPRIGHT COLUMN	9.60
ATV250- 19-7	SEALING RING	3.52
ATV250- 19-8	WIRE CLIP UNIT	9.60
ATV250- 19-9	BOLT	2.00
ATV250- 19-10	LOCKING SHIM	2.00
ATV250- 19-11	BUSHING	2.00
ATV250- 19-12	WASHER 10	2.00
ATV250- 19-13	NUT M10	2.00
ATV250- 19-14	COTTER PIN	2.00
ATV250- 19-15	STEERING TENSION ROD ASSY	107.20
ATV250- 19-15-1	Tire rod	4.80
ATV250- 19-15-2	STEERING TENSION ROD (in)	40.48
ATV250- 19-15-3	STEERING TENSION ROD (out)	40.48
ATV250- 19-15-4	NUT M6×1.25	2.00
ATV250- 19-15-5	COTTER PIN3.2×24	2.00

FIG. 20 STEERING BAR OPERATION SYSTEM




ATV250-	20-1	STEERING BAR TUBE	38.08
ATV250-	20-2	LEFT HANDLE BAR	9.60
ATV250-	20-3	THROTTLE CABLE	24.40
ATV250-	20-4	REAR BRAKE CABLE	23.86
ATV250-	20-5	THROTTLE LEVER ASSY	56.96
ATV250-	20-6	FRONT BRAKE CABLE ASSY	44.00
ATV250-	20-7	MAIN SWITCH COVER	21.16
ATV250-	20-7-2	DIGITAL DASH	314.00
ATV250-	20-8	SCREW M6×16	2.00
ATV250-	20-9		13.60

ATV250- **FIG. 21 OPERATION HANDLE BAR**



ATV250- 21-1	LEFT HANDLE BAR ASSY	25.12
ATV250- 21-2	LEFT LEVER ASSY	26.72
ATV250- 21-3	RIGHT LEVER ASSY	26.72
ATV250- 21-3-1	BRAKE SWITCH	9.40
ATV250- 21-4	HANDLE BAR BAND	2.00


FIG. 22 REAR WHEEL FORK ASSY



ATV250- 22-1	REAR WHEEL FORK UNIT	320.96
--------------	----------------------	--------

ATV250-	22-1-1	REAR ARM CONNECTION BOLT(LEFT)	3.52
ATV250-	22-1-2	REAR ARM CONNECTION BOLT(RIGHT)	3.52
ATV250-	22-1-3	REAR ARM NUT M22(RIGHT)	2.00
ATV250-	22-1-4	REAR ARM DUST-PROOF COVER	6.16
ATV250-	22-1-5	REAR ARM shaft bush	6.16
ATV250-	22-1-6	REAR ARM Connection bearing 30203	41.92
ATV250-	22-1-7	REAR ARM Connection oil seal25*40*7	8.16
ATV250-	22-2	REAR WHEEL AXLE SLEEVE	320.96
ATV250-	22-2-1	OIL SEAL	2.00
ATV250-	22-2-2	BEARING 6206-2RS	14.00
ATV250-	22-3	BOLT M12×25	2.00
ATV250-	22-4	NUT M12	2.00
ATV250-	22-5	DRIVING AXLE CLAMP UNIT(FRONT)	2.00
ATV250-	22-6	TRANSMISSION CASE PROTECTIVE COVER	40.48
ATV250-	22-7	BUFLEG PAD OF LOWER COVER OF GEAR BOX	2.00
ATV250-	22-8	BOLT M8×12	2.00
ATV250-	22-9	BOLT M10×1.25×25	2.00
ATV250-	22-10	DUST COVER	13.44


FIG. 23 REAR DRIVING GEAR BOX ASSY



ATV250-	23-1	REAR DRIVING GEAR ASSY	912.00
ATV250-	23-1-1	DRIVING GEAR BOX BODY	463.68
ATV250-	23-1-2	AIR-DRAINING JOINT	202.24
ATV250-	23-1-3	O-RING 85×3.55G	2.00
ATV250-	23-1-4	NUT M10×1.25	2.00
ATV250-	23-1-5	Oil seal 53.1*8.3	5.92
ATV250-	23-1-6	O-ring 58*2	1.28

ATV250-	23-1-7	Rear case ring	41.92
ATV250-	23-1-8	shaft gasket	36.64
ATV250-	23-1-9	bearing 6305	9.12
ATV250-	23-1-10	Adjust gasket	4.00
ATV250-	23-1-11	rear case driving gear	201.92
ATV250-	23-1-12	Roll bearing	64.16
ATV250-	23-1-13	discharge oil bolt	4.00
ATV250-	23-1-14	oil seal 63.1*8.5	7.84
ATV250-	23-1-15	charge oil bolt	3.20
ATV250-	23-1-16	oil seal 68.1*9	9.12
ATV250-	23-1-17	Roll bearing 556720	88.96
ATV250-	23-1-18	oil gasket	5.92
ATV250-	23-1-19	basin gear	247.36
ATV250-	23-1-20	Adjust gasket	4.16
ATV250-	23-1-21	bearing16013	53.60
ATV250-	23-1-22	oil seal 85*8.5	9.92
ATV250-	23-1-23	O-ring 150*3.10	1.92
ATV250-	23-2	DRIVING AXLE	71.36
ATV250-	23-3	CIRCLIP 21	2.00
ATV250-	23-4	GEAR BOX AIR -DRAIN	6.24
ATV250-	23-5	BRAKE AIR-DRAIN CLAMP	2.88


FIG. 24 Rear Axle



ATV250-	24-1	REAR RIM UNIT	118.00
ATV250-	24-2	REAR TIRE	120.00
ATV250-	24-3	REAR WHEEL CONNECTING PLATE ASSY	59.36
ATV250-	24-4	REAR BRAKE ASSY	215.50
ATV250-	24-4-1	rear brake drum	130.08
ATV250-	24-4-2	rear brake shoe	36.00


ATV250-	24-4-3	spring	3.00
ATV250-	24-4-4	rear brake oil seal	32.30
ATV250-	24-5	REAR WHEEL AXLE	178.30
ATV250-	24-6	WASHER 16	2.00
ATV250-	24-7	REAR WHEEL AXLE NUT M16	2.00
ATV250-	24-8	COTTER PIN 3.2×30	2.00
ATV250-	24-9	AIR FLOW PIPE OF REAR BRAKE	6.24
ATV250-	24-10	Rear axes dust washer	2.72
ATV250-	24-11	O-ring	3.00

FIG. 25 KICK STARTING OPERATION




ATV250-	25-1	BRACKET WELD	89.20
ATV250-	25-2	BOLT M10×22	2.00
ATV250-	25-3	STAND WELD (LEFT)	33.28
ATV250-	25-4	BOLT M8×16	2.00
ATV250-	25-5	NUT M8	2.00
ATV250-	25-6	STAND WELD (RIGHT)	33.28
ATV250-	25-7	REAR BRAKE PEDAL ASSY	56.96
ATV250-	25-8	REAR BRAKE TENSION ROD ASSY	12.00
ATV250-	25-9	WASHER	2.00
ATV250-	25-10	COTTER PIN	2.00
ATV250-	25-11	rear brake pedal circle spring	5.12

FIG. 26 FUEL TANK, FUEL COCK




ATV250-	26-1	FUEL TANK BODY	209.28
ATV250-	26-1-1	FUEL CAP	12.32
ATV250-	26-1-2	HOSE 5270-O5×15 (500mm)	8.48
ATV250-	26-1-3	FUEL SWITCH	20.96
ATV250-	26-1-4	Screw M6×16	2.00
ATV250-	26-1-5	RUBBER BUSH OF FUEL TANK	4.00
ATV250-	26-1-6	RUBBER BUSH OF FUEL TANK	4.00
ATV250-	26-2	INSTALLING BUSHING OF UPPER FUEL TANK LOWER	5.44
ATV250-	26-3	BOLT	2.00
ATV250-	26-4	INSTALLING BUSHING OF FUEL TANK	2.88
ATV250-	26-5	BOLT	2.00
ATV250-	26-6	FUEL INTAKE PIPE	5.92
ATV250-	26-7	STEEL WIRE CLASP	2.00
ATV250-	26-8	SUPPORTING DAMPER OF AIRFLOW PIPE	2.40
ATV250-	26-9	FUEL FILTER	5.00

FIG. 27 FRONT FENDER




ATV250- 27-1	FRONT FENDER	153.28
ATV250- 27-2	LEFT FRONT FENDER FLAP	22.72
ATV250- 27-3	RIGHT FRONT FENDER FLAP	22.72
ATV250- 27-4	R. PROTECTING PLATE	19.84
ATV250- 27-5	L. PROTECTING PLATE	19.84
ATV250- 27-6	R. gasoline tank plate	30.88
ATV250- 27-7	L. gasoline tank plate	30.88
ATV250- 27-8	HEADLIGHT COVER	46.08
ATV250- 27-9	UPPER COVER OF FUEL TANK	44.64
ATV250- 27-10	PAN HEAD SCREW	2.00
ATV250- 27-11	PLASTIC EXPANSION SCREW ASSY	2.00
ATV250- 27-12	FRONT FENDER SUPPORTING ROD	23.84
ATV250- 27-13	BOLT M3×16	2.00
ATV250- 27-14	HEADLIGHT ASSY	37.44
ATV250- 27-14-1	BULB 12V30W	7.20
ATV250- 27-15	SCREW 5×12	2.00

FIG. 28 REAR FENDER, TOOL KIT



ATV250- 28-1	REAR FENDER	198.08
ATV250- 28-2	LEFT PEDAL	17.44
ATV250- 28-3	RIGHT PEDAL	18.24
ATV250- 28-4	L. PROTECTING PLATE	16.00
ATV250- 28-5	R. PROTECTING PLATE	16.00
ATV250- 28-6	R. RR. PROTECTING PLATE	20.16
ATV250- 28-7	L. RR. PROTECTING PLATE	20.16
ATV250- 28-8	TOOL KIT UNIT	49.92
ATV250- 28-9	TOOL KIT CATCH	3.52
ATV250- 28-10	SHOCK PROOF PAD	2.00
ATV250- 28-11	PAN HEAD SCREW	2.00
ATV250- 28-12	NUT M6	2.00
ATV250- 28-13	TOOLBOX COVER	27.68


FIG. 29 SEAT



ATV250- 29-1 SEAT


178.40

FIG. 30 FRONT & REAR GUARD BRACKET



ATV250- 30-1	FENDER-GUARD	137.92
ATV250- 30-2	BOLT M8×16	2.00
ATV250- 30-3	NUT M3	2.00
ATV250- 30-4	FRONT LUGGAGE CARRIER	122.00
ATV250- 30-5	REAR LUGGAGE CARRIER	135.52
ATV250- 30-6	FRONT SAFEGUARD	30.88


FIG. 31 TAILLIGHT ASSY



ATV250- 31-1 TAILLIGHT ASSY
ATV250- 31-2 BULB

38.68
7.00

FIG. 32 ELECTRIC SYSTEM



ATV250- 32-1 CDI UNIT

68.00

ATV250- 32-2	RECTIFIER / REGULATOR	33.28
ATV250- 32-3	BOLT M6×25	2.00
ATV250- 32-4	SPRING WASHER 6	2.00
ATV250- 32-5	START RELAY	23.84
ATV250- 32-5-1	FUSE 10A	2.00
ATV250- 32-6	SHUTDOWN RELAY	28.64
ATV250- 32-7	HIGH PRESSURE COIL ASSY	42.00
ATV250- 32-7	PROTECTING CAP	3.84
ATV250- 32-8	BOLT UNIT M5×16	1.00
ATV250- 32-9	REVERSE SWITCH	7.68
ATV250- 32-10	NEUTRAL SWITCH	5.28
ATV250- 32-11	BATTERY ASSY	96.00
ATV250- 32-12	PRESSURE BLOCK OF BATTERY	6.08
ATV250- 32-13	FLANGE BOLT M6×20	2.00
ATV250- 32-14	BUFFER PAD OF BATTERY PRESSURE BLOCK	2.00
ATV250- 32-15	EARTH WIRE COMP	8.48
ATV250- 32-16	BATTERY POSITIVE LEAD	9.76
ATV250- 32-17	MAIN SWITCH LOCK	32.00
ATV250- 32-18	NEUTRAL INDICATOR ASSY	4.64
ATV250- 32-18-1	BULB 12V3W	7.00
ATV250- 32-19	REVERSE INDICATOR ASSY	7.00
ATV250- 32-20	HIGH BEAM INDICATOR ASSY	7.00
ATV250- 32-21	CABLE CLIP 3	2.88
ATV250- 32-22	CABLE BAND	2.00
ATV250- 32-23	HANDLE BAR BAND	2.00
ATV250- 32-24	CABLE	52.32
ATV250- 32-25		40.80