

KINGWAY NAKED 50CC 4T


PARTS CATALOGUE

www.skuteryostrojon.pl

1. ELECTRIC.	01
2. HANDLE BAR.....	3
3. FRAME COMP.....	03
4. WHEEL ASSY	7
5. COVER	9
6. ENGINE.....	11

□□□□□

NO□01





3 6 35 31 29 28 26 25

NO.	Part NO.	Description	Description in English	Qty	Price	Remark
1	XT50-20-1201000000	□□□□	HEADLIGHT	1		
2	XT50-20-1203010000	□□□□□□	FR.TURNING LIGHT.R	1		
3	XT50-20-1203011000	□□□□□□	FR.TURNING LIGHT.L	1		
4	XT50-20-1300000000	□□	METERS	1		
5	GB/T16674-1996	□□□□□□□M8×16	HEXAGON BOLT M8×16	2		
6	XT50-20-1216000000	□□□□	SIDE REFLECTOR	2		
7	GB/T818-2000	□□□□□□M6×35	BOLT M6×35	2		
8	XT50-20-1208023000	□□□□□□□□	BRACKET OF SEAT LOCK	1		
9	GB5783-86	□□□□□□M8×16	Inside hexangular bolt M8×16	2		
10	XT50-20-1208000000	□□□□	IGNITION LOCK	1		
11	GB5783-86	□□□□□□M5×25	Inside hexangular bolt M5×25	3		
12	GB/T818-2000	□□□□□□□M6×12	BOLT M6×12	1		
13	XT50-20-0300000001	□□□□	COVER OF FUEL TANK	1		
14	XT50-20-1208000001	□□	KEYS	2		
15	XT50-20-0904000000	□□□□□□	CABLE□SEAT LOCK	1		
16	XT50-20-0705000000	□□□□	WIRING HARNESS	1		
17	XT50-20-0701000001	□□□□□□□□	STOPPING SWITCH□SIDE STAND	1		
18	GB/T5781-2000	□□□□M6×16	BOLT M6×16	1		
19	XT50-20-1209000000	□□□□□□□□	BRAKE LAMP	1		
20	XT50-20-1705000004	□□□□□□□□	SPRING BRAKE SWITCH	1		
21	XT50-20-1203020000	□□□□□□	RR.TURNING LIGHT.R	1		

22	XT50-20-1203021000	□□□□□	RR.TURNING LIGHT.L	1		
23	XT50-20-1202000000	□□	TAILLIGHT	1		
24	XT50-20-1217000000	□□□□	REAR REFLECTOR	1		
25	XT50-20-0706020000	□□□	ASSY	1		
26	XT50-20-0706010000	□□□	RECTIFIER ASSY	1		
27	GB/T5781-2000	□□□□M6×16	BOLT M6×16	7		
28	XT50-20-1206000000	□□□	FLASHER	1		
29	XT50-20-0706040000	□□□	RELAY ASSY	1		
30	GB/T6177.1-2000	□□□□□M6	NUT M6	2		
31	XT50-20-0706030000	□□□	HIGH VOLTAGE WIRE ASSY	1		
32	GB/T95-2002	□□6*18	WASHER6*18	2		
33	XT50-20-0601030000	□□□	BATTERY TRESTLE	1		
34	XT50-20-0704000000	□□□	BATTERY	1		
35	XT50-20-1600000009	□□□□□	ENLAGE BAND	1		
36	XT50-20-1213000000	□□	HCR1	1		

□□□□□





NO.	Part NO.	Description	Description in English	Qty	Price	Remark
1	XT50-20-0802010001	STEERING COLUMN	STEERING COLUMN	1		
2	XT50-20-0802010009	UNDER COVER BEARING BOEWL	UNDER COVER BEARING BOEWL	2		
3	GB30879	UNDER BALL	UNDER BALL	20		
4	XT50-20-0802010008	UPPER COVER BEARING BOEWL	UPPER COVER BEARING BOEWL	2		
5	GB30879	UPPER BALL	UPPER BALL	20		
6	XT50-20-0802010006	NUT, ADJUST	NUT, ADJUST	1		
7	XT50-20-0802010007	COVER DUSTPROOF	COVER DUSTPROOF	1		
8	XT50-20-0802010004	LOCK NUT	LOCK NUT	1		
9	XT50-20-0908000001	HANDLE BAR	HANDLE BAR	1		
10	XT50-20-0904100000	MIRROR.R	MIRROR.R	2		
11	XT50-20-0904200000	MIRROR.L	MIRROR.L	2		
12	XT50-20-0906010000	SWITCH OF RIGHT HAND	SWITCH OF RIGHT HAND	1		
13	XT50-20-0906020000	SWITCH OF LEFT HAND	SWITCH OF LEFT HAND	1		
14	XT50-20-0802010100	equilibrium mass	equilibrium mass	2		
15	XT50-20-0802010003	DIRECTION HOLD CLIP	DIRECTION HOLD CLIP	2		
16	XT50-20-0802010002	UPPER BRACKET FR.FORK	UPPER BRACKET FR.FORK	1		

17	XT50-20-0906020001	□□□□	RIGHT GRIP	1		
18	XT50-20-0907020001	□□□	LEFT HANDLEBAR	1		
19	XT50-20-0802040001	□□□□□□	RUBBER BRACKET UNDER	2		
20	XT50-20-0802041000	□□□□□□	BRACKET, HEADLIGHT ASSY. P	2		
21	XT50-20-0802042000	□□□□□□	BRACKET, HEADLIGHT ASSY. L	2		
22	XT50-20-0802040002	□□□□□□	RUBBER BRACKET UPPER	2		
23	XT50-20-0802010002	□□□□□	FRONT LEFT ABSORBER ASSY	1		
24	XT50-20-0802010001	□□□□□	FRONT RIGHT ABSORBER ASSY	1		
25	XT50-20-0501030001	□□□□□□□□	Lower oil pipe flake	1		
26	GB/T5782-2000	□□□□□□M8×12	HEXAGON BOLT M8×12	4		
27	GB/T5782-2000	□□□□□□M8×30	HEXAGON BOLT M8×30	2		
28	XT50-20-0801010000	□□□□	RR.ABSORBER	1		
29	XT50-20-0801010000	□□□□	RR.ABSORBER	1		
30	GB/T95-2002	□□10	WASHER 10	4		
31	GB/T923□1988	□□□□□□M10	CASING NUT M10	4		
32	GB/T95-2002	□□12	WASHER 12	2		
33	XT50-20-0910000000	□□□□□□	CABLE COMP. INNER	1		
34	XT50-20-0901000000	□□□□□□□□	CABLE ASSY. CLUTCH	1		
35	XT50-20-0902000000	□□□□□□	WICKET CABLE	1		
36	XT50-20-0909000000	□□□	CHOKE CABLE	1		
37	XT50-20-0501030000	□□□□□□	Front brake assy	1		
38	XT50-20-0501030001	□□□□□□□□	Oil pipe flake	1		
39	GB/T5781-2000	□□□□M6×10	Bolt Flange M6×10	2		
40						

□□□□□□□□







NO.	Part NO.	Description	Description in English	Qty	Price	Remark
1	XT50-20-0600000000		VEHICLE FRAME	1		
2	XT50-20-0600000001		REAR RACK	1		
3	GB/T5782-2000	六角螺栓M6×10	HEXAGON BOLT M6×10	2		
4	GB/T5782-2000	六角螺栓M6×16	HEXAGON BOLT M6×16	4		
5	XT50-20-0605000000		TORQUE LINK COMP	1		
6	GB/T6170-1986	螺栓M8×30	BOLT M8×30	2		
7	GB/T95-2002	垫圈8	WASHER 8	2		
8	GB/T95-2002	垫圈8	WASHER 8	2		
9	GB/T6177.1-2000	螺母M8	NUT M8	2		

10	GB91□86	□□□2.0*25	COTTER PIN2.0*25	2		
11	XT50-20-1600000008	□□□□	CHAIN CUSHION	1		
12	XT50-20-0602000002	□□□ M12×208	SHAFT REAR FORK M12×208	1		
13	GB6187-86	□□□□□□□□M12	HEXAGON BOLT M12	1		
14	XT50-20-0602000000	□□□	REAR FORK	1		
15	XT50-20-1600000014	□□□	Rubber washer	1		
16	XT50-20-1112010000	□□□□	License packing block	1		
17	GB/T6177.1-2000	□□□□M6	Nut flange M6	4		
18	XT50-20-0905010000	□□□□□	PEDAL ASSY.,BRAKE	1		
19	XT50-20-1705000003	□□	SPRING OF BRAKE POLE	1		
20	XT50-20-1800000003	□□□□	ROD ASSY.,BRAKE	1		
21	XT50-20-1800000001	□□	BUSHING OF ASSY.,BRAKE	1		
22	GB/T5782-2000	□□□□□□M10×60	HEXAGON BOLT M10×60	6		
23	GB/T5782-2000	□□□□□□M10×20	HEXAGON BOLT M10×20	6		
24	XT50-20-0603100000	□□□□□	BAR COMP, FRONT STEP.R	1		
25	XT50-20-0603200000	□□□□□	BAR COMP, FRONT STEP.L	1		
26	GB/T5782-2000	□□□□□□M8×55	HEXAGON BOLT M8×55	6		
27	GB/T6177.1-2000	□□□□M8	Nut flange M8	4		
28	XT50-20-0602010000	□□□	REAR FOOTREST	2		
29	XT50-20-0602000001	□□□□	COVER OF FOOTREST.R	1		
30	XT50-20-0602000002	□□□□	COVER OF FOOTREST.L	1		
31	XT50-20-0604000000	□□□	CENTER STAND	1		
32	GB91□86	□□□2.5*30	COTTER PIN2.5*30	1		
33	GB/T95-2002	□□17	WASHER 17	2		
34	XT50-20-1800000002	□□□□	AXIS OF SIDE STAND	1		
35	XT50-20-1600000005	□□□□□□	BUFFER OF CENTER STAND	1		
36	XT50-20-1700000001	□□□□□	SPRING OF CENTER STAND	2		
37	XT50-20-1703000002	□□□□□	SPRING SIDE STAND	2		
38	GB6170-1986	□□□□□	Bolt OF SIDE STAND	1		

39	XT50-20-0603020000	□□□□□□	SIDE STAND	1		
40						





NO.	Part NO.	Description	Description in English	Qty	Price	Remark
1	XT50-20-0501010000		FRONT WHEEL	1		
2	XT50-20-0501000007	2.75-18	FRONT TYRE INNER TUBE	1		
3	XT50-20-0501031000		Arithmometer	1		
4	XT50-20-0501000002		BUSHING	1		
5	GB6187-86	M12	HEXAGON BOLT M12	1		
6	XT50-20-0501000001		BUSHING OF FRONT WHEEL	1		

7	XT50-20-0501030100	□□□	Brake disk	1		
8	XT50-20-0502000005	□□□	INSURANCE PIECE	2		
9	GB5783-86	□□□□M8×30	HEXAGON BOLT M8×30	4		
10	XT50-20-0502000007	□□□3.00-18□□□□□	REAR TYRE□INNER TUBE□	1		
11	XT50-20-0502010000	□□□	REAR WHEEL	1		
12	XT50-20-0502000006	□□□	CUSHION	4		
13	XT50-20-0502000001	□□□	BUSHING OF REAR WHEEL	1		
14	XT50-20-0502000003	□□□	BUSHING.R	1		
15	XT50-20-0502000002	□□□	BUSHING.L	1		
16	GB6187-86	□□□□□□□□M14	HEXAGON BOLT M14	1		
17	XT50-20-0502050000	□□□	CHAIN ADJUSTER	2		
18	XT50-20-0502000004	□□□	SPROCKET WHEEL PIECE	1		
19	XT50-20-0502040001	□□□□	PANEL COMP.BRAKE	1		
20	XT50-20-0502040002	□□□□	SHOE COMP.BRAKE	1		
21	XT50-20-0503000000	□□□□428*120	CHAIN 428*120	1		
22						

□□□□□□□□	NO□04					
	1		30	34	42	43
	2 4 5					




NO.	Part NO.	Description	Description in English	Qty	Price	Remark
1	XT50-20-0300000000		FUEL TANK	1		

2	XT50-20-1600000002	□□□□□□	R.CUSHION	1		
3	GB/T5782-2000	□□□□□□M6×35	HEXAGON BOLT M6×35	2		
4	GB/T96.1□2002	□□□□6	WASHER 6	2		
5	XT50-20-1600000003	□□□□	RUBBER□FUEL TANK	2		
6	XT50-20-1600000006	□□□□□□	RUBBER□PROTECTING PLATE	4		
7	XT125-18-1301000000	□□□□□□	Sensor assy	1		
8	GB/T6177.1-2000	□□□□M6	Nut flange M6	4		
9	XT125-18-0304000000	□□□□	Fuel switch	1		
10	XT50-20-1600000001	□□□□□□	F. CUSHION	2		
11	XT50-20-1109020000	□□□□	CARAPACE	1		
12	GB/T16674-1996	□□□□□□M6×16	HEXAGON BOLT M6×16	2		
13	GB/T95-2002	□□6	WASHER 6	2		
14	XT50-20-1107000001	□□□□	FRONT FENDER	1		
15	XT50-20-1808000000	□□□□□□	BRACKET OF FRONT FENDER	1		
16	XT50-20-1600000007	□□□□□□	CLIP OF SPEEDOMETER CABLE	1		
17	XT50-20-1107000100	□□□□	Decorative plank left	1		
18	XT50-20-1107000300	□□□□□□	Decorative soleplate left	1		
19	JB608.1-99	□□□□	CLIP	2		
20	GB/T845-1985	□□□□ST4.8×16	SELF-TAPPING SCREW ST4.8×16	4		
21	XT50-20-1107000400	□□□□□□	Decorative soleplate right	1		
22	XT50-20-1107000200	□□□□	Decorative plank right	1		
23	GB/T16674-1996	□□□□□□M6×16	HEXAGON BOLT M6×16	4		
24	GB/T95-2002	□□6	WASHER 6	2		
25	XT50-20-1107000500	□□□□	Bracket of left	1		
26	XT50-20-1107000600	□□□□	Bracket of right	1		
27	XT50-20-1101000003	□□□□□□	DECK PROTECTING PLATE L	1		
28	XT50-20-1600000007	□□□□	RUBBER□GING	1		
29	XT50-20-1101000001	□□□□	F.R PROTECTING PLATE L	1		
30	XT50-20-1101000002	□□□□	F.R PROTECTING PLATE R	1		
31	XT50-20-1101000004	□□□□□□	DECK PROTECTING PLATE R	1		

32	XT50-20-1600000008	□□□	RUBBER□GING	1		
33	XT50-20-1000000000	□□	SEAT CUSHION	1		
34	XT50-20-1103000002	□□□□	SIDE COVER R	1		
35	XT50-20-1103000001	□□□□	SIDE COVER L	1		
36	XT50-20-1600000009	□□□	RUBBER□GING	2		
37	GB/T96.1□2002	□□□□6	WASHER 6	4		
38	GB/T16674-1996	□□□□□□□M6×16	HEXAGON BOLT M6×16	2		
39	GB/T845-1985	□□□□ST4.2×16	SELF-TAPPING SCREW ST4.2×16	4		
40	JB608.1-99	□□□□	CLIP	2		
41	XT50-20-1106000000	□□□□□	REAR CENTER COVER	1		
42	GB/T16674-1996	□□□□□□□M8×35	HEXAGON BOLT M8×35	2		
43	XT50-20-1400000000	□□□	HAND HOLD	1		
44	XT50-20-1108010000	□□□	FRONT BODY, REAR	1		
45	XT50-20-1800000010	□□□□	PLATE, TAILLIGHT	1		
46	XT50-20-1600000009	□□□	RUBBER□GING	3		
47	GB/T96.1□2002	□□□□6	WASHER 6	6		
48	GB/T6177.1-2000	□□□□M6	Nut flange M6	6		
49	GB/T16674-1996	□□□□□□□M6×20	HEXAGON BOLT M6×20	2		
50	GB/T16674-1996	□□□□□□□M6×16	HEXAGON BOLT M6×16	2		
51	XT50-20-1109000002	□□□□	CHAIN CASE	1		
52	GB/T16674-1996	□□□□□□□M6×25	HEXAGON BOLT M6×25	2		
52						

□□□□□

NO□05



NO.	Part NO.	Description	Description in English	Qty	Price	Remark
1	XT50-20-0100000000	□□□	ENGINE	1		
2	XT50-20-0200000000	□□□□□	AIR FILTER	1		
3	XT50-20-0200000002	□□	CLIP OF AIR FILTER	1		
4	GB/T5783-2000	□□□□M6×25	HEXAGON BOLT M6×25	2		
5	XT50-20-0113000002	□□□	GASKET	1		
6	XT50-20-0101020000	□□□	INTAKE PIPE	1		
7	XT50-20-0113000001	□□□	GASKET	1		
8	GB/T5783-2000	□□□□M6×30	HEXAGON BOLT M6×30	3		
9	XT50-20-0113000000	□□□	CARBURETOR	1		
10	GB923□88	□□□□□□M6□□□	CASING NUT M6	2		
11	XT50-20-0400000001	□□□□□□	GASKET OF EXHAUST OUTLET	1		
12	XT50-20-0401050000	□□□	PAPER CUSHION	1		
13	GB/T5781-2000	□□□□M6×12	BOLT M6×12	2		
14	XT50-20-0401010000	□□□	AIR FUEL SUPPLY VALVE	1		
15	XT50-20-0401030000	□□□	CANNULATION	1		
16	XT50-20-0401040000	□□□	Muffler	1		
17	XT50-20-0400000000	□□□□□	MUFFLER ASSY	1		
18	XT50-20-0111050000	□□□	STARTING ARM COMP	1		
19	XT50-20-01030000035	□□□□□	LEFT CRANKCASE REAR COVER	1		
20	GB/T16674-1996	□□□□□□□M6×30	HEXAGON BOLT M6×30	2		
21	GB/T6177.1-2000	□□□□□□□M8	NUT M8	2		
22	GB5787□86	□□□□□□□M8×115	ENGINE BOLT M8×115	1		
23	GB5787□86	□□□□□□□M8×120	ENGINE BOLT M8×120	1		
24	GB/T5781-2000	□□□□□□M6×16	HEXAGON BOLT M6×16	1		
25	XT50-20-0111040000	□□□	GEARSHIFT PEDAL	1		
26	XT50-20-0111040001	□□	SPRING	1		

27						
----	--	--	--	--	--	--

www.skuteryostrow.pl

